

INSTRUCTION MANUAL



AUTOMATIC SHOE COVER DISPENSER PORTABLE

1. Start Up Instruction Shoe Cover Dispenser Portable



Open the lock in front of the dispenser and lift up the cover.



Press down both levers, each on one side, until they lock with a clicking noise.

Fix a pack of shoe covers (10pcs) at the 4 guiding bars. In total you can fill 5 packs (50pcs). Once you fixed one pack, remove the 4 fixation wires at the plastic rings.





Shoe dispenser filled up.



Loos the two side
Levers by pressing
onto the two plastic
fasteners.

Close the cover of the shoe
dispenser.
The shoe dispenser will now be
ready for use.



2. How To Use The Shoe Cover Dispenser Portable



The user (with common street shoes) will insert one foot after another into the dispenser and press the pedal down until the limit. The shoe cover will be pushed contactlessly over the street shoe.



Now you can enter the clean room with the maximum protection.
The shoe covers need to be disposed in special provided containers.